

Standards House
12 Doman Road
Camberley
Surrey
GU15 3DF
Tel: 01276 682841 Fax: 01276 691302
e-mail: instruments@signal-group.com
www.signal-group.com



MODEL 340 DISTRIBUTION OVEN SPECIFICATION

Designed to distribute hot, sample gas throughout the gas analyser system, the Model 340 Distribution Oven comprises a temperature controlled oven assembly, housing a particulate filter and needle-valve manifold arrangement.

Filter removal and needle-valve adjustment is easily achieved via the front panel, enabling individual flow control to three outlet ports.

Sample gas pressure is displayed on the front panel and a thermocouple socket on the rear panel allows sample temperature to be monitored.

Filter	:	Replaceable 0.1 micron fibreglass
Outlet number	:	3
Materials	:	316 stainless steel
Mains voltage	:	220/240V 50Hz 110/120V 50/60Hz
Power	:	750 watts
Weight	:	10 kg
Dimensions	:	19" rack x 3U 133(h) x 435(w) x 429(d) mm